Document No: B9818 Edition: 1

 Date:
 2019-07-30

 Page:
 1(1)

 Prepared:
 AN

 Approved:
 MS

ALO Center AB Industrivägen 10 SE-792 32 Mora Sweden +46 250 94900 info@alocenter.se

www.alocenter.se



ALO 9818

## **ALO 9818**

## Band loop accumulator



The band accumulator can be activated to generate a 12m loop of band at any time. When it's time to change coiler or cube the band end is locked and band is automatically fed into the loop accumulator allowing time to change coiler or cube. This will give time to weld coils together and facilitate continuous hardening/tempering. After welding, the band loop has been consumed allowing band to be feed directly from coiler or cube system again.

## THE SYSTEM COMPRISES:

Band loop table

## CAPACITY:

Band width: 20 - 80 mm Band thickness: 0.9 - 1.6 mm



SWEDISH QUALITY
WITH RESPECT FOR THE
ENVIRONMENT AND
SAFETY REGULATIONS

